Firmware update

Tools needed

FAT32 format Pendrive

1. Save the .hex file with the firmware update to install in the root of a USB stick. Never change the Firmware file's name. Always match the fixture model to its dedicated firmware file
2. Connect the USB memory stick to the USB connector of the KOSMOS back panel
3. Push the top knob and keep it pressed while power on the KOSMOS. It will automatically start the update process
4. Release the top knob. Once the firmware update process is finished the KOSMOS will reboot with the new firmware. Remove your USB memory stick

If you have problems with your device or with the update, please contact us at: customers@velvetlight.tv